

## Preventive Maintenance (PM) Schedule for BI-3000

The PM procedure is to maintain a fully functional operational machine. These steps should be done on quarterly (every 3 months) year schedule and should be done by a fully trained PM technician or an Allteq Field Service Engineer. This to prevent unnecessary adjustment or inadequate PM problems. If any parts need to be removed or/and cleaned, refer to your Maintenance & Diagnostics section of your machine manual. This will insure that the steps needed to remove and installed parts are properly taking care during the PM procedure and all necessary machine adjustment is done properly. If any problems arise, please contact your nearest Allteq representative to assist you in any problems do to improper PM procedure.

- Elevator leadscrew should be cleaned with alcohol or equivalent solvent using a clean lintfree cloth. Next lubricate with light machine oil. Remove any covers/plates needed to do this step. NOTE: "DO NOT USE ANY TYPES OF <u>GREASES</u> ON THE LEADSCREWS THIS WILL CAUSE YOU TO POSSIBLE HAVE INDEXING PROBLEMS"
- 2. Wipe off Elevator shafts with lint free cloth, no lubricant needed.
- 3. Remove/clean any debris that might be inside the machine such as excessive die coating materials, cotton tips, finger cots, pens, pencils, etc.
- 4. Check for any obstruction in or on the Wheel Guides, such as debris on the X-Y Stage. This can cause stiffness when moving the Chessman Ball when viewing devices.
- 5. The Bias Solenoid Cylinder Boat Biasing may need to be clean if not operating properly. Use alcohol to clean the shaft, **NO OILS** on shaft.
- 6. Remove any debris on the Front and Rear Rail slots. This can cause boat indexing problem, boat jamming and improper belt/o-ring wear. NOTE: If the Conveyor or Rail Assembly needs to be remove and cleaned refer to your manual or a qualified Allteq Service Engineer to ensure proper installation and/or setups, alignments and adjustments. If this is not done more problems could arise do to lack of knowledge of Special Adjustments need to maintain proper machine operation.
- 7. Clean/vacuum exhaust fans located inside for machine. After a period of time these collect dust and if not properly maintained can cause fans to function improperly.
- 8. Clean outside of machine with only soaps and water type of cleaning agents. Inspect outside unit for any broken/damaged items that may have occurred over a period of time. Repair as needed.
- 9. Check/clean air filter on back of machine.

This concludes the PM Schedule Operation for the BI-3000 unit. Refer to you machine manual for any other information needed.